



Android tablet Nobis NB09 Button Replacement

Open the Nobis NB09 tablet and replace broken or damaged buttons.

Written By: Jackson McAdams



INTRODUCTION

This guide demonstrates how to safely disassemble a Android tablet Nobis NB09 in order to replace broken or non-functional buttons.



TOOLS:

- [Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Button



- Use a screwdriver to remove the two 00 Phillips screws on the right side of the tablet.

Step 2




- Use the plastic opening tool to loosen, and pry off the back case.
⚠ Use caution when prying around the tablet ports so they do not crack.

Step 3



- The buttons are located on the bottom left hand corner of pink back plate. Simply pop old buttons out with spudger or similar tool.

Step 4



- Insert new buttons.

Step 5



- Close tablet and replace screws.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-28 06:51:48 PM.